# **Mobrey**

## Boiler water level controls

• Fully in accordance with the requirements of P.M.5, TRD604. pr EN12953-9 and 12952-11 and SAFed PSG2.

### Introduction

Mobrey originally entered the industrial boiler control market in 1923 with a range of steam operated equipment. Since that time the range has expanded to cover most aspects of control associated with the boiler house. Products range from electro-mechanical level devices to sophisticated electronic energy saving products that form a major step towards the fully automated boilerhouse. These reliable products are described in greater detail on the following pages and each carries the quality and service guarantee synonymous with the Mobrey name.

### **Alarm and Pump Control**

Mobrey Vertical Air Break Controls are a comprehensive range of magnetically operated water level controls. They are designed to meet all the requirements for automatic on/off control of boiler feed pump, burner cut-out, high and/or low level alarm or any combination of these. They comply fully with the recommendation of The British Health and Safety Executive Guidance Note P.M.5, and SAFed PSG2.

Float operated controls also comply with European standards TRD604. pr EN12953-9 and 12952-11 when used in conjuction with the ACCS unit described in BP203.



### Sequencing blowdown valves

The Mobrey Sequencing Valve is designed to function as a manually operated combined water isolating valve and sequencing valve. It provides positive purging of the water connection, float chamber and steam connection of a boiler control as required by P.M.5, TRD604. pr EN12953-9 and 12952-11 and SAFed PSG2.

Fail Safety, High Integrity, Self Monitoring Float operated level controls are inherently Fail-Safe and comply fully with the definitions for this parameter as stated by UK and European Standards. Float controls can be made to comply with the definitions of High Integrity and Self Monitoring by the addition of automatic checking equipment as described in Mobrey leaflet BP203. The equipment is unique because it actually carries out a dynamic test on the level equipment. which is a more searching requirement than an electrical integrity test. Again this equipment fully complies with the requirements of PM5, TRD604, SAFed PSG2 the harmonised European Standards pr EN12953-9 and 12592-11.

## **Conversion Heads**

These VABC heads are designed to fit into existing float chambers, and provide an economical method of updating boiler water level controls to the latest models. Conversion heads are available for on/off controls and modulators.

### Modulating water level controllers

The Mobrey Controller is a single element electrohydraulic control with an electronic feedback. The system comprises a control unit float chamber, a feedline modulating valve and a control box. It is used for the throttle control with the modulating valve in the feedline.





# Vertical air break alarm and pump controls Description

The Mobrey Vertical Air Break Controls (VABC) are a comphrensive range of magnetically operated water level controls for steam boilers. They are designed to meet all requirements for automatic on/off control of boiler feed pump, burner cut out, high and/or low level alarm or any combination of these complying fully with the recommendations of the British Health and Safety Executive, PM5

and SAFed PSG2 as well as European Standards TRD604, and pr EN12952-11 and 1253-9 when used in conjunction with the ACCS unit. See BP203. Refer to Fig. 6 for typical installations. Models available with Industrial (NEMA4), or Marine Heads. TUV approved models are available in Chambers and for Direct Mounting application.



## Operation

The Mobrey VABC is of glandless constuction. A primary permanent magnet attached to the float rod slides vertically inside a non-magnetic stainless steel centre tube and transmits the movements of the float to a secondary magnet in each switch unit. There are two pairs of contacts which are operated with a snap action and held by repulsion between the secondary magnet and the tertiary magnet of the switch unit assembly.

## Operating Levels Differentials

Each switch has a nominal fixed water level differential of 25mm between circuits A-A and B-B. To obtain a differential greater than 25mm, two switch units must be used.

The minimum water level differential for two switch units is 33mm, with switch centres positioned 8mm apart.

The maximum adjustable differential for two switch machines will vary with the operating range of each model, i.e. the distance between rising and falling level which is required to operate the switches positioned at the extreme ends of their adjustments - Fig. 2.

Switch adjustment - Fig. 1 and 2. Switches have adjustments as follows:

			IIXEU		
Range	Adjustment		differential		
62mm	37mm	+	25mm	=	62mm
150mm	125mm	+	25mm	=	150mm
250mm	225mm	+	25mm	=	250mm

Eivod

#### **Electrical Characteristics**

Single-pole double-throw operation for :


#### AC

Maximum voltage	440V
Maximum Current	5A
Minimum Power Factor	0.4
Maximum Power	2000VA
DC	
Resistive	
Maximum Power	100W
Maximum Voltage	250V
Maximum Current	5A

Inductive


Maximum Voltage 250V
\*Maximum Current 0.5A
Maximum Time Constant 40 ms
Maximum Power 100W

\*Maximum up to 2A dependent upon time constant of circuit, consult factory




Switches must not be used for the direct starting of motors. Contacts should be wired in series with the operating coils of relays, contact starters or solenoid valves, and fused separately.

Two 25mm BS.4568 cable entries are provided for the electrical connections. A sufficient length of flexible cable must be fitted to permit easy removal of the switch head and float assembly for routine maintenance.




## Dimensions and ordering information: Chamber mounted models

		No. of		Flanged &							
Type	Operating	Swite	ches	Screwed	Dimensions						
Number	Range	Std.	Max	Connections	С	G	Н	H,	L	W	F
Cast iron	chamber -	worki	ng pre	ssure: 13kg/cm <sup>2</sup>							
BX02/1	62	1	-	BS4504.25-16/11	ı	102	193	303	366	182	160
BX05/2	150	2	4	BS4504.25-16/11	ı	102	293	497	468	277	160
BX07/2	250	2	6	BS4504.25-16/11	ı	102	393	602	557	370	160
Fabricate	ed steel cha	mber	- work	ing pressure: 21k	g/c	m²					
BX09/1	62	1	-	BS4504.25-40/2	-	87	193	303	366	182	160
BX10/2	150	2	4	BS4504.25-40/2	-	87	293	497	468	277	160
BX11/2	250	2	6	BS4504.25-40/2	-	87	393	602	557	370	160
Fabricate	d steel cha	mber	- work	ing pressure: 32k	g/c	m²					
BX12/1	62	1	-	BS4504.25-40/2	-	102	193	303	559	372	160
BX13/2	150	2	4	BS4504.25-40/2	-	100	293	497	559	372	160
BX14/2	250	2	6	BS4504.25-40/2	-	100	393	602	559	372	160



					Screwed							
		No	. of		Bottom			Dim	ensi	one		
Type	Operating	Swit	ches	Flanged	Conn.			וווט	iensi	ons		
Number				Connections	BSP	С	G	Н	H,	L	W	F
Cast iro				pressure: 1								
BX03/1	62	1	-	25-16/11	1"	216	102	193	303	448	277	160
BX15/1	62	1	-	20-16/11	1"	180	100	193	303	480	240	160
BX87/1	62	1	-	20-16/11	1"	180	135	193	303	480	240	160
BX16/2	120	2	4	20-16/11	1"	180	100	293	497	480	240	160
BX88/2	120	2	4	20-16/11	1"	180	135	293	497	480	240	160
BX06/2	150	2	4	25-16/11	1"	216	102	293	497	448	277	160
BX08/2	250	2	6	25-16/11	1"	317	102	393	597	557	370	160
Fabricat	ed steel cl	namb	oer - v	working pres	sure: 21k	g/cm	l <sup>2</sup>					
BX17/1	62	1	-	20-40/2	1/2"	270	100	193	303	570	335	160
BX45/1	62	1	-	25-40/2	1/2"	270	100	193	303	570	335	160
BX18/2	120	2	4	20-40/2	1/2"	270	100	293	497	570	335	160
BX19/2	150	2	4	20-40/2	1/2"	270	100	293	497	570	335	160
BX20/2	150	2	4	25-40/2	1/2"	270	100	393	497	570	335	160
BX21/2	215	2	6	20-40/2	1/2"	270	100	393	602	570	335	160
BX22/2	215	2	6	25-40/2	1/2"			393	602	570	335	160
Fabricat	Fabricated steel chamber - working pressure: 32kg/cm <sup>2</sup>											
BX23/1	62	1		25-40/2	1/2"	350	112	193	303	595	372	160
BX24/2	150	2	4	25-40/2	1/2"	350	112	293	497	595	372	160
BX25/2	250	2	6	25-40/2	1/2"	350	112	393	597	595	372	160



## **Explanation of type numbers**

The type numbers are arbitrary except that BX denotes chamber mounting and BD direct mounting.

The stroke number indicates the number of switch units fitted as standard. When extra switches are required this stroke number will indicate the total number of switches to be provided.

When Marine models are required the letter 'M' should be inserted after the letters BX and before the number, e.g., the Industrial and NEMA 4 Model BX05/2 becomes BXM05/2 when in Marine construction.

Marine type approvals:
American Bureau of Shipping
Bureau Veritas
Germanischer Lloyd
Lloyds Register of Shipping
Det Norske Veritas
Russian Maritime Register of Shipping
TUV approved models (side and side connections only) are available on request. Before ordering please refer to Mobrey Measurement.

If the models shown here do not meet your specific requirements, please contact Mobrey Measurement for assistance.

### **Chamber Mounted Controls**

Float Chambers - manufactured in approved materials :-

Cast iron equal to BS. 1452 Grade 17 for up to 13kg/cm2 rating. Fabricated steel BS.3602 - HFS 27 for both 21kg/cm2 and 32kg/cm2 ratings. For chamber dimensions and process connections arrangement see dimension chart figures 3 and 4.

Switch head - containing one or more switch units mounted in a housing comprising a die-cast base with a zinc coated mild steel casing. Two 25mm BS.4568 cable entries are provided.


Switch units - have single pole double throw contacts, are latching and are positioned and held in place by clamp screws.


Centre tube - made of non-magnetic stainless steel and expanded into the top cover flange, it is fitted with a stop cap which also acts as a guide for the float rod carrying the primary magnet.

Float - manufactured in monel metal.

Float rod - manufactured in stainless steel.

For details on self testing/monitoring of chamber mounted controls refer to leaflet BP203.





The Chamber band mark indicates the lowest adjustment position of low level alarm and it is our recommendation that the positioning of the boiler control chambers relative to the water level gauge glasses and the N.W.L. is such that there is always water visible in the gauge glass even at the lowest operating band level.

### **Conversion Heads**

## Description


These Mobrey Vertical Air Break control heads are specifically designed to provide an economic method of updating old Mobrey mercury switch controls to the latest models. These 'Conversion Heads' will fit into existing chambers, and provide on/off pump control and alarm function.

Conversion Heads are also available for updating old Mobrey Teleflex Modulators.

A suitably adapted version of the Modulating Control head and float unit is provided for fitting into the existing float chamber. it will be necessary to replace the feed line valve with its modern counterpart and to provide the modern electronic control box.

#### Note

In all cases the type number of the existing equipment must be given when ordering. This is to enable us to check the model number and the float rod length to be provided. For the modulating control the basic information for sizing the valve lid and seat will be required.



### **Features**

- Save
  - Time
  - Money
  - Inconvenience
- · Conforms fully to PM5 requirements.
- · Uses existing wiring and chambers

If you cannot see the model number of your existing control listed here, or are unsure of which new model to order, please do not hesitate to contact Mobrey Measurement for further information.

## Ordering Information Type Numbers

Old unit numbers	Replacement unit
High and low	
alarms	00-0/0
100-MS6/F263	C250/2
102-MS6/F263	C250/2
129-MS70/F299	F250/2
129-MS71/F300 133-MS70/F299	F250/2
133-MS71/F300	F250/2
125-MS71/F301	F250/2
125-10157 1/F301	F250/2
Pump control and	
1st low alarms	
220-MS12/F284	C150/2
220-MS16/F284	C150/2
24-MS12/F216	C150/2
24-MS16/F216	C150/2
65-MS26/F22	C150/2
64-MS26/F280	C150/2
125-MS72/F295	C150/2
125-MS76/F295	C150/2
Single alarms 2nd	
low	
125-MS73/F296	
214-S90/F50	
14-S90/F50	
215-S90/F50	
15-S90/F50	
17-S101/F50	
18-S90/F50	
Modulating	
controls	
30310	
30295	

## **Direct mounted water level controllers**

## Direct mounted models Standard models

Direct Mounted Vertical Air Break
Controls employ the same principles
of operation and piece parts as the
chamber mounted equivalents except
that the chamber is exchanged
for a large round flange and the
tube assembly for mounting the
control directly on to the boiler shell
connection. A stilling or guide tube
should be provided, which may be
fixed or removable, to ensure that
the float rod is not damaged and
the correct vertical movement is
achieved.

# Direct mounted controls incorporating test facilities


These controls have the provision for testing the operation of the mechanism without lowering the level of water in the boiler. Testing can be initiated manually or by a timer.

U.K. Patent 1279504 or 1473939 and foreign equivalents.

## Hydraulic cup test facility

The test is achieved by lowering the float to the low water alarm level, by the following means:

The float road includes a cup. above the float, which is fed with water from the boiler feed pump via small bore pipework and valves through the control mounting flange (see fig. 7) for approximately 24 seconds. The additional weight overcomes the buoyancy of the float, causing it to sink, stop the burner firing and operate the alarm system. After closing the test valve in the supply from the feed pump to the control, a small hole in the bottom of the cup drains off the water, permitting the float to rise to the normal operating position. Control of the water supply to the cup can alternatively be by means of a solenoid valve, which can




be initiated by a timer or a manually operated push button.

In this design the alarm switch remains fully adjustable.


## **Electromagnetic test facility**

The switch head includes an inductive coil below the single switch subassembly (Fig. 8). This surrounds an armature located inside the stainless steel centre tube and fixed to the float rod. To initiate the test cycle, the coil can be energised by a timer or a manually operated push button and the float will be thrust downwards to stop the burner firing and operate the alarm system. When the coil is de-energised the float rises to its normal level. In this design

the alarm switch unit is not adjustable.



## **Dimensions and Ordering Informaton: Direct Mounted Models**



Туре	Working press.	Operating	No o	f	Connection K	Float dim	Di	mension	ıs	Max. float
number	at saturated	range	swite	ches std.	BS4504	length dia	D	Н	H,	rod length
Standard	steam kg/cm <sup>2</sup>		max.	•			Min		· ·	
BD01/1		62	1	1				193	303	
BD02/2	21.0	150	2	4	100-40/2	152 x 67	77	293	497	765
BD03/2		250	2	6				393	597	
BD04/1		62	1	1				193	303	
BD05/2	32.0	150	2	4	100-40/2	155 x 90	100	293	497	
BD06/2		250	2	6				393	597	1016
Pressures up to 32	2kg/cm² available c	n request								
Hydraulic cup										
test facility										
BDT01/1	32.0	62	1	1				193	303	
BDT02/2		150	2	4	100-40/2	155 x 90	100	293	497	1016
BDT03/2		250	2	6				393	597	
Electromagnetic										
test facility	21.0									
BDT04/1	32.0	-	1	-	BM128mm sq	155 x 90	100	293	497	1016
BDT05/1		-	1	-	100-40/2		. 30	293	497	

# Modulating water level controllers Description

The Mobrey Modulating Controller is a single element electro-hydraulic control with an electronic feedback system comprising:

- i) A control unit float chamber, mounted on the boiler shell, fitted with an Inductance Coil 'A' head assembly which can be made suitable for either Industrial or Marine Applications.
- ii) A flanged modulating valve, fitted with an Inductance Coil 'B' and twin solenoid valve assembly, which is mounted in the boiler feed water line.
- iii)An electronic control box.

### Operation

A positive change of water level in the boiler alters the inductance value of Coil "A" causing an imbalance in the system. This signal is transmitted through the electronic control box to the appropriate solenoid valve on the modulating valve thus producing a change of hydraulic pressure on the piston assembly, the movement of which modulates the flow of water to the boiler. Simultaneously this same vertical travel creates a change in the inductance value of Coil "B" until the balance is restored, thus closing the solenoid valve and hydraulically locking the modulating valve spindle. This sequence is repeated in very small steps until the feed water input equals the required evaporation rate of the boiler.

To prevent the modulating valve responding to random water movement against the general direction of level change, a 13mm reversal or (dead) band is incorporated in the electronic circuitry.

Low water alarm and burner cut out contacts are also provided within the control box to operate when the water level falls to a predetermined position.

#### **Installation Note:**

For the further safety of boilers it is recommended that the Mobrey Control Unit is mounted on a Mobrey Sequencing Valve.

The water connection from the boiler to the float chamber should be as short as possible and the control head float chamber should be mounted close to the gauge glasses.

The chamber band mark indicates the lowest adjustment position of the low level alarm and it is our recommendation that the positioning of the boiler control chambers relative to the water level gauges glasses and the N.W.L. is such that there is always water visible in the gauge glass even at the lowest operating band level. If required our technical staff will advise on individual installations.

### **General Note**

Models shown are for 21kg/cm² maximum working pressure. Details of modules for 32kg/cm² will be provided on request.

## **Important Notice**

Electronic control box must not be subjected to either vibration or excessive temperature. It is therefore recommended that they are NOT mounted directly on to the boiler shell.

### **Features**

- Inherently stable
- Easily adjusted for individual operating requirements
- · Instant reversion to hand control in emergency.

# Application Notes Throttle Control -

- · Modulating valve in feed line.
- · Suitable for automatic cold start conditions.
- Used for all pumps capable of operating against a closed discharge.


With a rising water level in the boiler, the modulating valve closes progressively to reduce the rate of feed into the boiler. The size of valve lid is determined by the *actual* capacity of the boiler plus an allowance. See nomogram on page 9.

## Power failure and high water shutdown – with a third solenoid valve


Where one pump is feeding more than one boiler it is imperative that a boiler cannot be overfilled. Therefore a third solenoid valve can be installed on the modulating valve which is operated by either a loss of power on the boiler control circuit or the high water alarm. In either case the valve will be closed and prevent further water entering the boiler. The third solenoid valve can be retrofitted to existing valves.

## Common feed pump arrangement

Multi-boiler installations operating on a common feed system require special sizing consideration and full details should be provided so that a suitable valve can be recommended.




# Control Units Standard control heads and chambers




Type number	81006	81007	81008	81951
Material	Cast iron	Fabricated	Fabricated	Forged
		steel	steel	steel flange
Max. press.				
kg/cm2	13	21	21	32
Connections	Side &	Side &	Side &	Direct
	bottom	bottom	side	mounted
	BS4504	BS4504	ND 25	BS4504
	25-16/11	25-40/2	NW 25	100/40/2
Α	468	468	570	-
В	100	100	100	-
С	102	87	100	-
D	277	277	335	-
E	390	390	390	390
F	430	430	430	430
G	-	-	270	-

Models are available for up to 32kg/cm<sup>2</sup> steam working. Details on request

### **Control Box**



## Modulating Valves



## **Electrical characteristics**

Type number	80436	80660
Input supply	240V ac	110V ac
	50/60Hz <u>+</u> 10%	50/60Hz <u>+</u> 10%

Input circuit protected by 1 amp HRC fuse.

Output option: 0-10V available on request.

Alarm and control relays protected by 2 amp HRC fuses.

Relay contacts voltage free rating:-

Max. voltage 250V ac Max. current 2 amp
Facility available to special order for separate supply to
solenoid valves with 2 amp HRC maximum protection.

## **IMPORTANT NOTICE**

Electronic control box must not be subjected to either vibration or excessive temperature. It is therefore recommended that they are not mounted directly on to the boiler shell.

		No. of	
Туре		solenoid	Electrical
number	Flanged	valves	supply
80310/*	Table H	2	230V ac 50Hz
80311/*	ND40	2	230V ac 50Hz
80653/*	NW40	2	110V ac 50Hz
80486/*	NW40	2	230V ac 60Hz
80310/80435/*	Table H	3	230V ac 50Hz
80311/80435/*	ND40	3	230V ac 50Hz
80653/80435/*	NW40	3	110V ac 50Hz

\* Stroke letter to indicate valve lid size required:

Α	200	В	150
С	406	D	140
E	425		

**Note** The internal trim on the Modulating valve can be changed without the need to replace the valve should operating conditions change.

### Sizing of Valve Lids

A range of valve lids and associated seats are available and provide linear flow characteristics. a table of cv values for water (S.G.=1) is given below for valve lids in the fully open position.

Type of Lid	Cv = kg/hr for 1 kg/cm²
Α	1,690
В	2,260
С	3,030
D	4,100
E	5,480
F	7,480
G	9,840
Н	13,520
I	18,480

Note: J Lid available on request for larger boilers.

Formulae for determining the Cv value and correct size of valve lid are given below. The pressure drop across the valve should be 1.4 kg/cm² or greater – normally, the higher the pressure drop the better the degree of control. The lid size is that with the nearest Cv value above the calculated value.

In the following example, an allowance of 0.4 kg/cm² has been made for all feed line losses. In practice, the allowance should be that of the installation under consideration and may well be in excess of 0.4 kg/cm², particularly where the feed pump is remote from the boiler and/or where an anti-syphon valve adjacent to the boiler feed check valve has been fitted.

Where

**Q** = Actual Evaporation of Boiler plus 15 per cent margin kg/hr.

**P** = Pump Discharge Pressure kg/cm² when passing Q quantity of water minus (Boiler Maximum Working Pressure plus 0.4 kg/cm²). Example:

Boiler evaporation (actual)

= 4,000 kg/hr.

**Boiler Working Pressure** 

 $= 6.6 \text{ kg/cm}^2$ 


Pump Discharge Pressure at

Q quantity

 $= 11 \text{ kg/cm}^2$ 

Lid required: Type C.

## Mobrey Modulating Level Controller valve size chart



Note: Conversion heads to convert old Mobrey Teleflex modulators to the latest models are available.

## **Sequencing Blowdown Valves**

## Description

A purpose built flanged isolating angle and sequencing valve with ½" BSP screwed drain connection and back seating features, all valve trims are in stainless steel. It fully complies with the recommendations of Health and Safety Executive guidance note PM5 - for automatically controlled steam and hot water boilers.

### **Function**

The Mobrey sequencing valve is designed to function as a combined water isolating valve and a sequencing valve to provide positive purging of the water connection, float chamber and steam connection of a boiler control.


Blowdown of float chamber and connections is effected separately and in a pre-determined sequence by the operation of the single specially designed handwheel.

### **Features**


- One valve to provide separate blowdown of:
  - Control Chamber
  - Steam Connection
  - Water Connection
- · Blowdown by predetermined sequence
- · Stainless steel trim
- Back seating ensures packings are not subjected to continuous pressure
- Available with Imperial or Metric flanges Available for pressures up to 32 kgs/cm²



## Sequence of operation



## **Dimensions and Ordering Information**



#### Models availble

Type Flange Connections		Material Maximum Body and Working		Dimensions					
Trainisor	BS4504	Stuffing Box	Pressure Bar	Α	В	С			
80938	25-16/11	Cast Iron	13*	83	54	219			
80947	25-25/21	Gunmetal	21	83	54	219			
80951	25-40/1	Cast Steel	32	83	54	219			
81390	BS10 Table H	Gunmetal	21	83	54	210			

<sup>\*</sup>For Lloyds applications maximum W.P. is 10.5 Bar

## **Important**

The blowdown connection should be piped directly to an independent covered drain, or tundish with removable lid, capable of accepting the full discharge without danger of blow-back. The bore of blowdown pipe should not be less than 12mm and the length should be kept as short as possible. Sight glasses must not be fitted in the blowdown line.

## **Blowdown Procedure Card:**

Mobrey produce a useful blowdown procedure card, part number BP109, which is available on request.

### **Associated Boiler Products**

#### **Electronic Probes**

Mobrey Measurement manufact-ures a full range of conductive and capacitive probe controls for application on steam boilers. This equipment fully complies with the latest boiler specifications.

### **Automatic Control Check System (ACCS)**

This product has been designed to provide high integrity and self-monitoring to float operated controls in compliance with the latest boiler standards

#### Steam and water Flow

Flow meters are available for steam, water and fuel flow measurement using orifice and low energy loss averaging pitot tube technology. Non intrusive meters are available for liquid flow.

#### **General Level**

Mobrey Measurement is a level, flow, pressure, density and viscosity measurement instrument company. If you have a problem we will have the solution

### **Smoke Density**

Self-calibrating, Obscuration Meters available on request

# TDS Control, Timed Bottom Blowdown, Remote Alarm & Shut down panels

## For UK and Eire markets only – Full customer service provision

Mobrey Measurement is able to provide a full design, installation, commissioning and maintenance service for site installed instrumentation through it's Service Division. This organisation is able to provide a full boiler house installation and maintenance service and provide turnkey installation solutions covering all control and instrumentation functions. The following gives a typical list of operations carried out by engineers and technicians directly employed by the company and operating through 5 regional offices throughout the UK

- Total compliance with unmanned boiler regulations, Health and Safety guidance note PM5, SAFed PSG2, and prEN12953-9 and prEN12952-11 for both existing Mobrey float controls and electronic probe installation
- Steam and water flow monitoring, heat and mass flow calculation using Mobrey's unique range of products.
- Tank and level monitoring solutions using Mobrey's unique range of products.
- Complete automation solutions bringing together major manufacturers equipment into a single turnkey solution Mobrey Measurement Service Division is an engineering company providing engineering solutions.



Insurance inspection



High integrity, self-monitoring float controls



Electronic probe installation



Flowmetering

Head Office Tel: 01753 756634 756622 756623

Fax: 01753 579523

Scotland, N Ireland & Eire Tel: 0141 613 1441 Fax: 0141 613 2093 Northern Installation Tel: 0161 209 4450 Fax: 0161 480 6297 Southern Installation Tel: 01474 355976 Fax: 01474 564349

International

Emerson Process Management Mobrey Measurement 158 Edinburgh Avenue, Slough, Berks UK SL1 4UE T +44 (0) 1753 756600 F +44 (0) 1753 823589 www.mobrey.com

